

FILTASILT OIL/SEDIMENT



FILTASILT 
 Dirty to clean in one easy process



PRODUCT

Filtsilt is an innovative solution for sediment separation. Portable and easy to handle, Filtsilt is ideal for day to day use. It removes oil from water down to 3.5 parts per million and solids down to 80 microns, meaning it is suitable to pump onto open ground.

Filtsilt is a unique and simple to use. It connects easily to any pump and comes complete with a adaptor to suit any diameter hose, from 3 inches to half and inch. The filter has a highly visible indicator strip, which turns blue when the Filtsilt has reached its capacity.

Reusable

Filtsilt is ideal for compliance on-site and is cost-effective. Save money on what would usually require an expensive tanker removal. It is ideal for use in construction utilities, ground works, excavations, manholes, dykes, gullies, watercourse works, bridge maintenance, drilling and many more.

TYPE	OIL-ONLY
PRODUCT CODE	D107FMULTI
SIZE	1200mm x 400mm

ADDITIONAL INFORMATION

Transport: No specific regulation, inert properties.
 Security: No specific risk. For further information please refer to the Material Safety
 Storage: Store in a dry place.
 Disposal: Oils and liquids must be disposed of in compliance with the absorbed liquid destruction Regulation.



Renowned experts in the supply of Spill Prevention, Containment, Control Products & Services