

# 20 X 25LTR CHEMSTOR<sup>®</sup> STEEL BUNDED STORE



### PRODUCT

The base of this unit is manufactured from 3mm mild steel sheet while the back, sides and door panels are pressed from 2mm mild steel sheet, which is corrugated as required for additional strength and the roof (fully welded around the perimeter) is pressed and fitted with suitable bracing.

This model has double, hinged lockable (keyed handle) doors, high and low level louvre vents fitted with flame arrestor mesh, a single full length, full depth shelf and a fully seam welded sump which complies with all the current regulations relating to capacities (covered with galvanised steel grid mesh panels). The underside of the unit is fitted with forklift transport hoops which also help eliminate contact with ground and reduce the risk of corrosion. Prior to painting the unit is fully shot blasted to provide a clean and keyed surface.

This model can hold up to 20 x 25ltr cans. Vents are optional extras and must be specified when ordering

### PRODUCT NO

F3111575

### ADDITIONAL INFORMATION

Transport:	No specific regulation, inert properties.
Security:	No specific risk. For further information please refer to the Material Safety
Storage:	Store in a dry place.
Disposal:	Liquid must be disposed of in compliance with the absorbed liquid destruction Regulation.

*Be spill prepared not ill prepared*