

### 80 X 25LTR + SMALL CONTAINERS CHEMSTOR<sup>®</sup> STEEL BUNDED STORE



#### PRODUCT

A 2mm pressed steel welded body construction provides the structural strength for this unit, while the roof which is fitted with lifting eyes is manufactured from 3mm mild steel. The two easy glide sliding doors are constructed from 2mm mild steel and are fitted with a central lock and padlock points (padlocks not supplied).

Constructed from 3mm mild steel, the sump is fully seam welded and is as you would expect fully compliant with all current UK regulations relating to capacities and the underside is fitted with plinths to eliminate contact with ground and reduce the risk of corrosion. High- and low-level louvre vents complete with flame arrestor mesh are fitted as standard and the unit is fitted with 2 full length/half depth shelves and 1 full length,  $\emptyset$  depth shelf at the top. Prior to painting the unit is fully shot blasted to provide a clean and keyed surface.

This model can hold up to 80 x 25ltr cans plus small containers on the top shelf.

#### PRODUCT NO

F3117228

#### ADDITIONAL INFORMATION

Transport:	No specific regulation, inert properties.
Security:	No specific risk. For further information please refer to the Material Safety
Storage:	Store in a dry place.
Disposal:	Liquid must be disposed of in compliance with the absorbed liquid destruction Regulation.

*Be spill prepared not ill prepared*