

# STEEL COVERED SINGLE IBC SPILL PALLET



## PRODUCT

Manufactured from medium-density polyethylene this spill pallet, designed to hold 1 x 1000ltr IBC has a 0.6mm galvanised steel (powder coated paint finish) cover fitted with hinged doors and retaining catches to hold them open during loading and unloading.

The metal cover is secured to the spill pallet by means of M8 dome head Allen bolts & nyloc nuts.

PRODUCT NO	DIMENSIONS	SUMP	UDL	WEIGHT
P3201816	1840mm x 1425mm x 2405mm	1100L	2000kg	223kg

## ADDITIONAL INFORMATION

Transport:	No specific regulation, inert properties.
Security:	No specific risk. For further information please refer to the Material Safety
Storage:	Store in a dry place.
Disposal:	Liquid must be disposed of in compliance with the absorbed liquid destruction Regulation.

*Be spill prepared not ill prepared*